

BIG FAN-DMX



Mode/Channel			Channel Name	DMX	Function
105CH	15CH	10CH			
1	1	1	fan continuously rotating	0	no function
				1-127	gobo rotating, slow to fast
				128	stop
				129-255	reverse gobo rotating, slow to fast
2	2	2	Dimmer	0-255	0-100%
3	3	3	Strobe	0-19	off
				20-24	on
				25-64	strobe 1, fast to slow
				65-69	on
				70-84	strobe 2 (fast on, slow off), fast to slow
				85-89	on
				90-104	strobe 3 (slow on, fast off), fast to slow
				105-109	on
				110-124	strobe 4 (random), fast to slow
				125-129	on
				130-144	strobe 5 (random fast on, slow off), fast to slow
				145-149	on
				150-164	strobe 6 (random slow on, fast off), fast to slow
				165-169	on
				170-184	strobe 7 (pulse strobe), fast to slow
				185-189	on
				190-204	strobe 8 (random pulse strobe), fast to slow
				205-209	on
				210-224	strobe 9 (fade), fast to slow
				225-229	on
230-244	strobe 10 (pulse strobe), fast to slow				
245-255	on				
4	4		Color	0	no function
				1-2	2700K(R=156, G=118, B=0, W=63)
				3-4	3200K(R=156, G=141, B=5, W=89)
				5-6	4200K(R=156, G=141, B=14, W=255)
				7-8	5600K(R=156, G=207, B=54, W=255)
				9-10	8000K(R=130, G=255, B=96, W=255)
				11	Blue (R=0, G=0, B=255, W=0)
				12-48	R=0, G+, B=255, W=0
				49	Cyan (R=0, G=255, B=255, W=0)
				50-86	R=0, G=255, B-, W=0
				87	Green (R=0, G=255, B=0, W=0)
				88-124	R+, G=255, B=0, W=0
				125	Yellow (R=255, G=255, B=0, W=0)
				126-162	R=255, G-, B=0, W=0
				163	Red (R=255, G=0, B=0, W=0)
				164-200	R=255, G=0, B+, W=0
				201	Magenta (R=255, G=0, B=255, W=0)
				202-238	R-, G=0, B=255, W=0
				239	Blue (R=0, G=0, B=255, W=0)
				240-247	Color fade, fast to slow
248-255	Color jump, fast to slow				
5	5		Pattern	0	no function



Mode/Channel			Channel Name	DMX	Function
105CH	15CH	10CH			
5	5		Pattern	1	pattern 1
				2	pattern 2
				3	pattern 3
			
				253	pattern 253
				254	pattern 254
				255	pattern 255
6	6	4	LED built-in	000-015	no function
				16	LED built-in 1
				17	LED built-in 2
				18	LED built-in 3
				.	.
				.	.
				.	.
				107	LED built-in 91
				108	LED built-in 92
				109-135	LED built-in (main built-int)
				136	LED built-in 94
				137	LED built-in 95
				138	LED built-in 96
				.	.
				.	.
.	.				
224	LED built-in 183				
225	LED built-in 184				
226	LED built-in 185				
227-255	LED built-in 186				
7	7	5	LED built-in speed	0-127	fast to slow
				128	stop
				129-255	reverse slow to fast
8	8	6	LED built-in delay	0-255	fast to slow
9	9	7	Background color	0	no function
				1-2	2700K(R=156, G=118, B=0, W=63)
				3-4	3200K(R=156, G=141, B=5, W=89)
				5-6	4200K(R=156, G=141, B=14, W=255)
				7-8	5600K(R=156, G=207, B=54, W=255)
				9-10	8000K(R=130, G=255, B=96, W=255)
				11	Blue (R=0, G=0, B=255, W=0)
				12-48	R=0, G+, B=255, W=0
				49	Cyan (R=0, G=255, B=255, W=0)
				50-86	R=0, G=255, B-, W=0
				87	Green (R=0, G=255, B=0, W=0)
				88-124	R+, G=255, B=0, W=0
				125	Yellow (R=255, G=255, B=0, W=0)
				126-162	R=255, G-, B=0, W=0
				163	Red (R=255, G=0, B=0, W=0)
164-200	R=255, G=0, B+, W=0				
201	Magenta (R=255, G=0, B=255, W=0)				
202-238	R-, G=0, B=255, W=0				



Mode/Channel			Channel Name	DMX	Function
105CH	15CH	10CH			
9	9	7	Background color	239	Blue (R=0, G=0, B=255, W=0)
				240-247	Color fade, fast to slow
				248-255	Color jump, fast to slow
10	10	8	Background color dimmer	0-255	0-100%
11	11	9	Control	0-9	no function
				10-14	no function
				15-19	reserved
				20-24	no function
				25-29	no function
				30-34	reserved
				35-39	reserved
				40-44	reserved
				45-49	reserved
				50-54	no function
11	11	9	Control	55-59	no function
				60-64	no function
				65-69	reserved
				70-74	all reset
				75-79	reserved
				80-84	no function
				85-89	no function
				90-94	no function
				95-99	no function
				100-104	no function
				105-109	no function
				110-114	no function
				115-119	no function
				120-124	no function
				125-129	no function
				130-134	no function
				135-139	dimmer fast mode
				140-144	dimmer smooth mode
145-149	dimmer curve Linear				
150-154	dimmer curve Square				
155-159	dimmer curve I Squa				
160-164	dimmer curve Scurve				
165-169	no function				
170-174	no function				
175-255	no function				
12	12		R all	0-255	0-100%
13	13		G all	0-255	0-100%
14	14		B all	0-255	0-100%
15	15	10	UV all	0-255	0-100%
16			R1	0-255	0-100%
17			G1	0-255	0-100%
18			B1	0-255	0-100%
19			R2	0-255	0-100%
20			G2	0-255	0-100%

BIG FAN-DMX



Mode/Channel			Channel Name	DMX	Function
105CH	15CH	10CH			
21			B2	0-255	0-100%
.....				
103			R30	0-255	0-100%
104			G30	0-255	0-100%
105			B30	0-255	0-100%