



T3X BEAM-DMX

Advanced: 19CH Basic: 16CH

| Mode/Channel | | Channel Name | DMX | Function |
|--------------|------------------------------------|-------------------|---------|------------------------------------|
| 19CH | 16CH | | | |
| 1 | 1 | Pan | 0-255 | 0-540 |
| 2 | 2 | Pan 16bit | 0-255 | 16bit adjustable |
| 3 | 3 | Tilt | 0-255 | 0-270 |
| 4 | 4 | Tilt 16bit | 0-255 | 16bit adjustable |
| 5 | 5 | Pan/Tilt speed | 0-255 | fast to slow |
| 6 | 6 | Dimmer | 0-255 | 0-100% |
| 7 | | Dimmer 16bit | 0-255 | 16bit adjustable |
| 8 | 7 | Strobe | 0-7 | off |
| | | | 8-15 | on |
| | | | 16-131 | synchronized strobe, slow to fast |
| | | | 132-167 | fast close slow open, slow to fast |
| | | | 168-203 | slow close fast open, slow to fast |
| | | | 204-239 | pulse strobe, slow to fast |
| | | | 240-250 | random strobe, slow to fast |
| | | | 251-255 | on |
| 9 | 8 | Color wheel | 0-4 | white |
| | | | 5-8 | color 1 |
| | | | 9-12 | color 9 |
| | | | 13-16 | color 3 |
| | | | 17-20 | color 4 |
| | | | 21-24 | color 5 |
| | | | 25-28 | color 6 |
| | | | 29-32 | color 7 |
| | | | 33-36 | color 8 |
| | | | 37-40 | color 7 |
| | | | 41-44 | color 3 |
| | | | 45-48 | color 11 |
| | | | 49-52 | color 12 |
| | | | 53-56 | color 13 |
| | | | 57-60 | color 8 |
| | | | 61-127 | split color |
| 128-189 | color scroll, fast to slow | | | |
| 190-193 | stop | | | |
| 194-255 | reverse color scroll, slow to fast | | | |
| 10 | 9 | Static gobo wheel | 0-3 | open |
| | | | 4-6 | gobo 1 |
| | | | 7-9 | gobo 2 |
| | | | 10-12 | gobo 3 |
| | | | 13-15 | gobo 4 |

T3X BEAM-DMX

Advanced: 19CH Basic: 16CH



| Mode/Channel | | Channel Name | DMX | Function |
|--------------|------------------------------------|-------------------|---------|--------------------------------------|
| 19CH | 16CH | | | |
| 10 | 9 | Static gobo wheel | 16-18 | gobo 5 |
| | | | 19-21 | gobo 6 |
| | | | 22-24 | gobo 7 |
| | | | 25-27 | gobo 8 |
| | | | 28-30 | gobo 9 |
| | | | 31-33 | gobo 10 |
| | | | 34-36 | gobo 11 |
| | | | 37-39 | gobo 12 |
| | | | 40-42 | gobo 13 |
| | | | 43-45 | gobo 14 |
| | | | 46-48 | gobo 15 |
| | | | 49-51 | gobo 16 |
| | | | 52-55 | gobo 17 |
| | | | 56-59 | open |
| | | | 60-63 | gobo 1 shaking, slow to fast |
| | | | 64-67 | gobo 2 shaking, slow to fast |
| | | | 68-71 | gobo 3 shaking, slow to fast |
| | | | 72-75 | gobo 4 shaking, slow to fast |
| | | | 76-79 | gobo 5 shaking, slow to fast |
| | | | 80-83 | gobo 6 shaking, slow to fast |
| | | | 84-87 | gobo 7 shaking, slow to fast |
| | | | 88-91 | gobo 8 shaking, slow to fast |
| | | | 92-95 | gobo 9 shaking, slow to fast |
| | | | 96-99 | gobo 10 shaking, slow to fast |
| | | | 100-103 | gobo 11 shaking, slow to fast |
| | | | 104-107 | gobo 12 shaking, slow to fast |
| 108-111 | gobo 13 shaking, slow to fast | | | |
| 112-115 | gobo 14 shaking, slow to fast | | | |
| 116-119 | gobo 15 shaking, slow to fast | | | |
| 120-123 | gobo 16 shaking, slow to fast | | | |
| 124-127 | gobo 17 shaking, slow to fast | | | |
| 128-189 | reverse color scroll, fast to slow | | | |
| 190-193 | stop | | | |
| 194-255 | color scroll, slow to fast | | | |
| 11 | 10 | Prism 1 | 0-4 | off |
| | | | 5-255 | prism |
| 12 | 11 | Prism 1 rotating | 0-127 | prism index |
| | | | 128-189 | prism reverse rotating, fast to slow |
| | | | 190-193 | stop |

T3X BEAM-DMX

Advanced: 19CH Basic: 16CH



| Mode/Channel | | Channel Name | DMX | Function |
|--------------|----------------------|------------------|---------|--------------------------------------|
| 19CH | 16CH | | | |
| 12 | 11 | | 194-255 | prism rotating, slow to fast |
| 13 | 12 | prism 2 | 0-4 | off |
| | | | 5-255 | prism |
| 14 | 13 | Prism 2 rotating | 0-127 | prism index |
| | | | 128-189 | prism reverse rotating, fast to slow |
| | | | 190-193 | stop |
| | | | 194-255 | prism rotating, slow to fast |
| 15 | 14 | Frost | 0-255 | frost |
| 16 | 15 | Focus | 0-255 | 0-100% |
| 17 | | Built-in | 0-7 | off |
| | | | 8-15 | pan/tilt built-in 1 |
| | | | 16-23 | pan/tilt built-in 2 |
| | | | 24-31 | pan/tilt built-in 3 |
| | | | 32-39 | pan/tilt built-in 4 |
| | | | 40-47 | pan/tilt built-in 5 |
| | | | 48-55 | pan/tilt built-in 6 |
| | | | 56-63 | pan/tilt built-in 7 |
| | | | 64-71 | pan/tilt built-in 8 |
| | | | 72-79 | pan/tilt built-in 9 |
| | | | 80-87 | pan/tilt built-in 10 |
| | | | 88-95 | pan/tilt built-in 11 |
| | | | 96-103 | pan/tilt built-in 12 |
| | | | 104-111 | pan/tilt built-in 13 |
| | | | 112-119 | pan/tilt built-in 14 |
| | | | 120-127 | pan/tilt built-in 15 |
| | | | 128-135 | pan/tilt built-in 16 |
| | | | 136-143 | pan/tilt built-in 17 |
| | | | 144-151 | pan/tilt built-in 18 |
| | | | 152-159 | pan/tilt built-in 19 |
| | | | 160-167 | pan/tilt built-in 20 |
| | | | 168-175 | pan/tilt built-in 21 |
| | | | 176-183 | pan/tilt built-in 22 |
| | | | 184-191 | pan/tilt built-in 23 |
| | | | 192-199 | pan/tilt built-in 24 |
| | | | 200-207 | pan/tilt built-in 25 |
| | | | 208-215 | pan/tilt built-in 26 |
| | | | 216-223 | pan/tilt built-in 27 |
| | | | 224-231 | pan/tilt built-in 28 |
| 232-239 | pan/tilt built-in 29 | | | |

T3X BEAM-DMX

Advanced: 19CH Basic: 16CH



| Mode/Channel | | Channel Name | DMX | Function |
|--------------|----------------------|----------------|---------|---------------------------|
| 19CH | 16CH | | | |
| 17 | | Built-in | 240-247 | pan/tilt built-in 30 |
| | | | 248-255 | pan/tilt built-in 31 |
| 18 | | Built-in speed | 0-255 | fast to slow |
| 19 | 16 | Control | 0-69 | off |
| | | | 70-79 | pan/tilt blackout enable |
| | | | 80-89 | pan/tilt balckout disable |
| | | | 90-99 | color blackout enable |
| | | | 100-109 | color blackout disable |
| | | | 110-119 | gobo blackout enable |
| | | | 120-129 | gobo blackout disable |
| | | | 130-139 | lamp on |
| | | | 140-149 | pan/tilt reset |
| | | | 150-159 | color reset |
| | | | 160-169 | gobo reset |
| | | | 170-179 | strobe/prism reset |
| | | | 180-189 | off |
| | | | 190-199 | focus reset |
| | | | 200-209 | all reset |
| | | | 210-219 | all blackout enable |
| 220-229 | all blackout disable | | | |
| 230-239 | lamp off | | | |
| 240-255 | off | | | |