



| Mode/Channel |       |      |      |      |      | Channel Name     | DMX     | Function                         |
|--------------|-------|------|------|------|------|------------------|---------|----------------------------------|
| 135CH        | 111CH | 64CH | 30CH | 24CH | 15CH |                  |         |                                  |
| 1            | 1     | 1    | 1    | 1    | 1    | Pan              | 0-255   | 0-540                            |
| 2            | 2     | 2    | 2    | 2    | 2    | Pan 16bit        | 0-255   | 16bit adjustable                 |
| 3            | 3     | 3    | 3    | 3    | 3    | Tilt             | 0-255   | 0-260                            |
| 4            | 4     | 4    | 4    | 4    | 4    | Tilt 16bit       | 0-255   | 16bit adjustable                 |
| 5            | 5     | 5    | 5    | 5    | 5    | Pan/Tilt speed   | 0-255   | fast to slow                     |
| 6            | 6     | 6    | 6    | 6    |      | CTC              | 0       | no function                      |
|              |       |      |      |      |      |                  | 1-255   | from 19000K to 2700K             |
| 7            | 7     | 7    | 7    | 7    | 13   | color 1 (ring)   | 0-4     | no function                      |
|              |       |      |      |      |      |                  | 5-9     | color 1                          |
|              |       |      |      |      |      |                  | 10-14   | color 2                          |
|              |       |      |      |      |      |                  | 15-19   | color 3                          |
|              |       |      |      |      |      |                  | 20-24   | color 4                          |
|              |       |      |      |      |      |                  | 25-29   | color 5                          |
|              |       |      |      |      |      |                  | 30-34   | color 6                          |
|              |       |      |      |      |      |                  | 35-39   | color 7                          |
|              |       |      |      |      |      |                  | 40-44   | color 8                          |
|              |       |      |      |      |      |                  | 45-49   | color 9                          |
|              |       |      |      |      |      |                  | 50-54   | color 10                         |
|              |       |      |      |      |      |                  | 55-59   | color 11                         |
|              |       |      |      |      |      |                  | 60-64   | color 12                         |
|              |       |      |      |      |      |                  | 65-69   | color 13                         |
|              |       |      |      |      |      |                  | 70-74   | color 14                         |
|              |       |      |      |      |      |                  | 75-79   | color 15                         |
|              |       |      |      |      |      |                  | 80-84   | color 16                         |
|              |       |      |      |      |      |                  | 85-89   | color 17                         |
|              |       |      |      |      |      |                  | 90-94   | color 18                         |
|              |       |      |      |      |      |                  | 95-99   | color 19                         |
|              |       |      |      |      |      |                  | 100-104 | color 20                         |
|              |       |      |      |      |      |                  | 105-109 | color 21                         |
|              |       |      |      |      |      |                  | 110-114 | color 22                         |
|              |       |      |      |      |      |                  | 115-119 | color 23                         |
|              |       |      |      |      |      |                  | 120-124 | color 24                         |
|              |       |      |      |      |      |                  | 125-129 | color 25                         |
|              |       |      |      |      |      |                  | 130-134 | color 26                         |
|              |       |      |      |      |      |                  | 135-139 | color 27                         |
|              |       |      |      |      |      |                  | 140-144 | color 28                         |
|              |       |      |      |      |      |                  | 145-149 | color 29                         |
|              |       |      |      |      |      |                  | 150-154 | color 30                         |
|              |       |      |      |      |      |                  | 155-159 | color 31                         |
|              |       |      |      |      |      |                  | 160-164 | color 32                         |
|              |       |      |      |      |      |                  | 165-169 | color 33                         |
|              |       |      |      |      |      |                  | 170-174 | color 34                         |
|              |       |      |      |      |      |                  | 175-179 | no function                      |
|              |       |      |      |      |      |                  | 180-201 | color fade, fast to slow         |
|              |       |      |      |      |      |                  | 202-207 | stop                             |
|              |       |      |      |      |      |                  | 208-229 | reverse color fade, fast to slow |
|              |       |      |      |      |      |                  | 230-234 | no function                      |
|              |       |      |      |      |      |                  | 235-249 | Color jump, fast to slow         |
|              |       |      |      |      |      |                  | 250-255 | no function                      |
| 8            | 8     | 8    | 8    | 8    | 13   | color 2 (center) | 0-4     | no function                      |
|              |       |      |      |      |      |                  | 5-9     | color 1                          |
|              |       |      |      |      |      |                  | 10-14   | color 2                          |
|              |       |      |      |      |      |                  | 15-19   | color 3                          |
|              |       |      |      |      |      |                  | 20-24   | color 4                          |
|              |       |      |      |      |      |                  | 25-29   | color 5                          |
|              |       |      |      |      |      |                  | 30-34   | color 6                          |
|              |       |      |      |      |      |                  | 35-39   | color 7                          |
|              |       |      |      |      |      |                  | 40-44   | color 8                          |
|              |       |      |      |      |      |                  | 45-49   | color 9                          |
|              |       |      |      |      |      |                  | 50-54   | color 10                         |
|              |       |      |      |      |      |                  | 55-59   | color 11                         |
|              |       |      |      |      |      |                  | 60-64   | color 12                         |
|              |       |      |      |      |      |                  | 65-69   | color 13                         |
|              |       |      |      |      |      |                  | 70-74   | color 14                         |
|              |       |      |      |      |      |                  | 75-79   | color 15                         |
|              |       |      |      |      |      |                  | 80-84   | color 16                         |



| Mode/Channel |       |      |      |      |      | Channel Name     | DMX     | Function                         |
|--------------|-------|------|------|------|------|------------------|---------|----------------------------------|
| 135CH        | 111CH | 64CH | 30CH | 24CH | 15CH |                  |         |                                  |
| 8            | 8     | 8    | 8    | 8    | 13   | color 2 (center) | 85-89   | color 17                         |
|              |       |      |      |      |      |                  | 90-94   | color 18                         |
|              |       |      |      |      |      |                  | 95-99   | color 19                         |
|              |       |      |      |      |      |                  | 100-104 | color 20                         |
|              |       |      |      |      |      |                  | 105-109 | color 21                         |
|              |       |      |      |      |      |                  | 110-114 | color 22                         |
|              |       |      |      |      |      |                  | 115-119 | color 23                         |
|              |       |      |      |      |      |                  | 120-124 | color 24                         |
|              |       |      |      |      |      |                  | 125-129 | color 25                         |
|              |       |      |      |      |      |                  | 130-134 | color 26                         |
|              |       |      |      |      |      |                  | 135-139 | color 27                         |
|              |       |      |      |      |      |                  | 140-144 | color 28                         |
|              |       |      |      |      |      |                  | 145-149 | color 29                         |
|              |       |      |      |      |      |                  | 150-154 | color 30                         |
|              |       |      |      |      |      |                  | 155-159 | color 31                         |
|              |       |      |      |      |      |                  | 160-164 | color 32                         |
|              |       |      |      |      |      |                  | 165-169 | color 33                         |
|              |       |      |      |      |      |                  | 170-174 | color 34                         |
|              |       |      |      |      |      |                  | 175-179 | no function                      |
|              |       |      |      |      |      |                  | 180-201 | color fade, fast to slow         |
|              |       |      |      |      |      |                  | 202-207 | stop                             |
|              |       |      |      |      |      |                  | 208-229 | reverse color fade, fast to slow |
|              |       |      |      |      |      |                  | 230-234 | no function                      |
|              |       |      |      |      |      |                  | 235-249 | Color jump, fast to slow         |
|              |       |      |      |      |      |                  | 250-255 | no function                      |
| 9            | 9     | 9    | 9    | 9    |      | Pattern          | 0-3     | no function                      |
|              |       |      |      |      |      |                  | 4       | pattern 1                        |
|              |       |      |      |      |      |                  | 5       | pattern 2                        |
|              |       |      |      |      |      |                  | 6       | pattern 3                        |
|              |       |      |      |      |      |                  | .       | .                                |
|              |       |      |      |      |      |                  | 253     | pattern 250                      |
|              |       |      |      |      |      |                  | 254     | pattern 251                      |
|              |       |      |      |      |      |                  | 255     | pattern 252                      |
| 10           | 10    | 10   | 10   | 10   |      | LED built-in     | 0-5     | no function                      |
|              |       |      |      |      |      |                  | 6-10    | LED built-in 1                   |
|              |       |      |      |      |      |                  | 11-15   | LED built-in 2                   |
|              |       |      |      |      |      |                  | 16-20   | LED built-in 3                   |
|              |       |      |      |      |      |                  | 21-25   | LED built-in 4                   |
|              |       |      |      |      |      |                  | 26-30   | LED built-in 5                   |
|              |       |      |      |      |      |                  | 31-35   | LED built-in 6                   |
|              |       |      |      |      |      |                  | 36-40   | LED built-in 7                   |
|              |       |      |      |      |      |                  | 41-45   | LED built-in 8                   |
|              |       |      |      |      |      |                  | 46-50   | LED built-in 9                   |
|              |       |      |      |      |      |                  | 51-55   | LED built-in 10                  |
|              |       |      |      |      |      |                  | 56-60   | LED built-in 11                  |
|              |       |      |      |      |      |                  | 61-65   | LED built-in 12                  |
|              |       |      |      |      |      |                  | 66-70   | LED built-in 13                  |
|              |       |      |      |      |      |                  | 71-75   | LED built-in 14                  |
|              |       |      |      |      |      |                  | 76-80   | LED built-in 15                  |
|              |       |      |      |      |      |                  | 81-85   | LED built-in 16                  |
|              |       |      |      |      |      |                  | 86-90   | LED built-in 17                  |
|              |       |      |      |      |      |                  | 91-95   | LED built-in 18                  |
|              |       |      |      |      |      |                  | 96-100  | LED built-in 19                  |
|              |       |      |      |      |      |                  | 101-105 | LED built-in 20                  |
|              |       |      |      |      |      |                  | 106-110 | LED built-in 21                  |
|              |       |      |      |      |      |                  | 111-115 | LED built-in 22                  |
|              |       |      |      |      |      |                  | 116-120 | LED built-in 23                  |
|              |       |      |      |      |      |                  | 121-125 | LED built-in 24                  |
|              |       |      |      |      |      |                  | 126-130 | LED built-in 25                  |
|              |       |      |      |      |      |                  | 131-135 | LED built-in 26                  |
|              |       |      |      |      |      |                  | 136-140 | LED built-in 27                  |
|              |       |      |      |      |      |                  | 141-145 | LED built-in 28                  |
|              |       |      |      |      |      |                  | 146-150 | LED built-in 29                  |
|              |       |      |      |      |      |                  | 151-155 | LED built-in 30                  |
|              |       |      |      |      |      |                  | 156-160 | LED built-in 31                  |
|              |       |      |      |      |      |                  | 161-165 | LED built-in 32                  |



| Mode/Channel |       |      |      |      |      | Channel Name       | DMX     | Function                                          |
|--------------|-------|------|------|------|------|--------------------|---------|---------------------------------------------------|
| 135CH        | 111CH | 64CH | 30CH | 24CH | 15CH |                    |         |                                                   |
| 10           | 10    | 10   | 10   | 10   |      | LED built-in       | 166-170 | LED built-in 33                                   |
|              |       |      |      |      |      |                    | 171-175 | LED built-in 34                                   |
|              |       |      |      |      |      |                    | 176-180 | LED built-in 35                                   |
|              |       |      |      |      |      |                    | 181-185 | LED built-in 36                                   |
|              |       |      |      |      |      |                    | 186-190 | LED built-in 37                                   |
|              |       |      |      |      |      |                    | 191-195 | LED built-in 38                                   |
|              |       |      |      |      |      |                    | 196-200 | LED built-in 39                                   |
|              |       |      |      |      |      |                    | 201-205 | LED built-in 40                                   |
|              |       |      |      |      |      |                    | 206-210 | LED built-in 41                                   |
|              |       |      |      |      |      |                    | 211-215 | LED built-in 42                                   |
|              |       |      |      |      |      |                    | 216-255 | no function                                       |
| 11           | 11    | 11   | 11   | 11   |      | LED built-in speed | 0-127   | fast to slow                                      |
|              |       |      |      |      |      |                    | 128     | stop                                              |
|              |       |      |      |      |      |                    | 129-255 | reverse slow to fast                              |
| 12           | 12    | 12   | 12   | 12   |      | LED built-in delay | 0-255   | fast to slow                                      |
|              |       |      |      |      |      |                    | 0       | no function                                       |
|              |       |      |      |      |      |                    | 1-2     | 2700K(R=156, G=118, B=0, W=63)                    |
|              |       |      |      |      |      |                    | 3-4     | 3200K(R=156, G=141, B=5, W=89)                    |
|              |       |      |      |      |      |                    | 5-6     | 4200K(R=156, G=141, B=14, W=255)                  |
|              |       |      |      |      |      |                    | 7-8     | 5600K(R=156, G=207, B=54, W=255)                  |
|              |       |      |      |      |      |                    | 9-10    | 8000K(R=130, G=255, B=96, W=255)                  |
|              |       |      |      |      |      |                    | 11      | Blue (R=0, G=0, B=255, W=0)                       |
|              |       |      |      |      |      |                    | 12-48   | R=0, G+, B=255, W=0                               |
|              |       |      |      |      |      |                    | 49      | Cyan (R=0, G=255, B=255, W=0)                     |
|              |       |      |      |      |      |                    | 50-86   | R=0, G=255, B-, W=0                               |
|              |       |      |      |      |      |                    | 87      | Green (R=0, G=255, B=0, W=0)                      |
|              |       |      |      |      |      |                    | 88-124  | R+, G=255, B=0, W=0                               |
|              |       |      |      |      |      |                    | 125     | Yellow (R=255, G=255, B=0, W=0)                   |
|              |       |      |      |      |      |                    | 126-162 | R=255, G-, B=0, W=0                               |
|              |       |      |      |      |      |                    | 163     | Red (R=255, G=0, B=0, W=0)                        |
|              |       |      |      |      |      |                    | 164-200 | R=255, G=0, B+, W=0                               |
|              |       |      |      |      |      |                    | 201     | Magenta (R=255, G=0, B=255, W=0)                  |
|              |       |      |      |      |      |                    | 202-238 | R-, G=0, B=255, W=0                               |
|              |       |      |      |      |      |                    | 239     | Blue (R=0, G=0, B=255, W=0)                       |
|              |       |      |      |      |      |                    | 240-247 | Color fade, fast to slow                          |
|              |       |      |      |      |      |                    | 248-255 | Color jump, fast to slow                          |
| 13           | 13    | 13   | 13   | 13   |      | Background color   | 0-255   | 0-100%                                            |
| 14           | 14    | 14   | 14   | 14   |      | Background color   | 0-255   | 0-100%                                            |
| 15           | 15    |      |      |      |      | Background color   | 0-255   | 0-100%                                            |
| 16           | 16    | 15   | 15   | 15   | 6    | Dimmer 1 (ring)    | 0-255   | 0-100%                                            |
| 17           | 17    |      | 16   |      | 7    | Dimmer 1 (ring)    | 0-255   | 0-100%                                            |
| 16           | 18    | 16   | 17   | 16   | 6    | Dimmer 2 (center)  | 0-255   | 0-100%                                            |
| 17           | 19    |      | 18   |      | 7    | Dimmer 2 (center)  | 0-255   | 0-100%                                            |
| 18           | 20    | 17   | 19   | 17   | 8    | strobe 1 (ring)    | 0-19    | off                                               |
|              |       |      |      |      |      |                    | 20-24   | on                                                |
|              |       |      |      |      |      |                    | 25-69   | strobe 1, fast to slow                            |
|              |       |      |      |      |      |                    | 70-89   | strobe 2 (fast on, slow off), fast to slow        |
|              |       |      |      |      |      |                    | 90-109  | strobe 3 (slow on, fast off), fast to slow        |
|              |       |      |      |      |      |                    | 110-129 | strobe 4 (random), fast to slow                   |
|              |       |      |      |      |      |                    | 130-149 | strobe 5 (random fast on, slow off), fast to slow |
|              |       |      |      |      |      |                    | 150-169 | strobe 6 (random slow on, fast off), fast to slow |
|              |       |      |      |      |      |                    | 170-189 | strobe 7 (pulse strobe), fast to slow             |
|              |       |      |      |      |      |                    | 190-209 | strobe 8 (random pulse strobe), fast to slow      |
|              |       |      |      |      |      |                    | 210-229 | strobe 9 (fade), fast to slow                     |
|              |       |      |      |      |      |                    | 230-244 | strobe 10 (pulse strobe), fast to slow            |
|              |       |      |      |      |      |                    | 245-255 | on                                                |
| 19           | 21    | 18   | 20   | 18   | 8    | strobe 2 (center)  | 0-19    | off                                               |
|              |       |      |      |      |      |                    | 20-24   | on                                                |
|              |       |      |      |      |      |                    | 25-69   | strobe 1, fast to slow                            |
|              |       |      |      |      |      |                    | 70-89   | strobe 2 (fast on, slow off), fast to slow        |
|              |       |      |      |      |      |                    | 90-109  | strobe 3 (slow on, fast off), fast to slow        |
|              |       |      |      |      |      |                    | 110-129 | strobe 4 (random), fast to slow                   |
|              |       |      |      |      |      |                    | 130-149 | strobe 5 (random fast on, slow off), fast to slow |
|              |       |      |      |      |      |                    | 150-169 | strobe 6 (random slow on, fast off), fast to slow |
|              |       |      |      |      |      |                    | 170-189 | strobe 7 (pulse strobe), fast to slow             |
|              |       |      |      |      |      |                    | 190-209 | strobe 8 (random pulse strobe), fast to slow      |
|              |       |      |      |      |      |                    | 210-229 | strobe 9 (fade), fast to slow                     |



| Mode/Channel |       |      |      |      |      | Channel Name      | DMX                | Function                                  |
|--------------|-------|------|------|------|------|-------------------|--------------------|-------------------------------------------|
| 135CH        | 111CH | 64CH | 30CH | 24CH | 15CH |                   |                    |                                           |
| 19           | 21    | 18   | 20   | 18   | 8    | strobe 2 (center) | 230-244<br>245-255 | strobe 10 (pulse strobe), fast to slow on |
| 20           | 22    | 19   | 21   | 19   | 14   | Zoom              | 0-255              | from small to big                         |
| 21           | 23    | 20   | 22   | 20   | 15   | Control           | 0-9                | no function                               |
|              |       |      |      |      |      |                   | 10-14              | pan/tilt blackout                         |
|              |       |      |      |      |      |                   | 15-19              | reserved                                  |
|              |       |      |      |      |      |                   | 20-24              | reserved                                  |
|              |       |      |      |      |      |                   | 25-29              | reserved                                  |
|              |       |      |      |      |      |                   | 30-34              | combine channel enable                    |
|              |       |      |      |      |      |                   | 35-39              | combine channel disable                   |
|              |       |      |      |      |      |                   | 40-44              | defrost fan on                            |
|              |       |      |      |      |      |                   | 45-49              | defrost fan off                           |
|              |       |      |      |      |      |                   | 50-54              | pan reset                                 |
|              |       |      |      |      |      |                   | 55-59              | tilt reset                                |
|              |       |      |      |      |      |                   | 60-64              | zoom reset                                |
|              |       |      |      |      |      |                   | 65-69              | reserved                                  |
|              |       |      |      |      |      |                   | 70-74              | all reset                                 |
|              |       |      |      |      |      |                   | 75-79              | reserved                                  |
|              |       |      |      |      |      |                   | 80-84              | reserved                                  |
|              |       |      |      |      |      |                   | 85-89              | reserved                                  |
|              |       |      |      |      |      |                   | 90-94              | reserved                                  |
|              |       |      |      |      |      |                   | 95-99              | reserved                                  |
|              |       |      |      |      |      |                   | 100-104            | reserved                                  |
|              |       |      |      |      |      |                   | 105-109            | reserved                                  |
|              |       |      |      |      |      |                   | 110-114            | reserved                                  |
|              |       |      |      |      |      |                   | 115-119            | reserved                                  |
|              |       |      |      |      |      |                   | 120-124            | fan ECO                                   |
|              |       |      |      |      |      |                   | 125-129            | fan FULL                                  |
|              |       |      |      |      |      |                   | 130-134            | fan AUTO                                  |
|              |       |      |      |      |      |                   | 135-139            | dimmer fast mode                          |
|              |       |      |      |      |      |                   | 140-144            | dimmer smooth mode                        |
|              |       |      |      |      |      |                   | 145-149            | no function                               |
|              |       |      |      |      |      |                   | 150-154            | Square curve                              |
|              |       |      |      |      |      |                   | 155-159            | I Square curve                            |
| 21           | 23    | 20   | 22   | 20   | 15   |                   | 160-164            | Scurve                                    |
|              |       |      |      |      |      |                   | 165-169            | white mode                                |
|              |       |      |      |      |      |                   | 170-174            | full mode                                 |
|              |       |      |      |      |      |                   | 175-179            | color calibration off when single color   |
|              |       |      |      |      |      |                   | 180-184            | color calibration on when single color    |
|              |       |      |      |      |      |                   | 185-239            | no function                               |
|              |       |      |      |      |      |                   | 240-247            | color calibration on                      |
|              |       |      |      |      |      |                   | 248-255            | color calibration off                     |
| 22           | 24    | 21   | 23   | 21   | 9    | R(C) all          | 0-255              | 0-100%                                    |
| 23           | 25    |      | 24   |      |      | R(C) all 16bit    | 0-255              | 0-100%                                    |
| 24           | 26    | 22   | 25   | 22   | 10   | G(M) all          | 0-255              | 0-100%                                    |
| 25           | 27    |      | 26   |      |      | G(M) all 16bit    | 0-255              | 0-100%                                    |
| 26           | 28    | 23   | 27   | 23   | 11   | B(Y) all          | 0-255              | 0-100%                                    |
| 27           | 29    |      | 28   |      |      | B(Y) all 16bit    | 0-255              | 0-100%                                    |
| 28           | 30    | 24   | 29   | 24   | 12   | W all             | 0-255              | 0-100%                                    |
| 29           | 31    |      | 30   |      |      | W all 16bit       | 0-255              | 0-100%                                    |
| 30           |       |      |      |      |      | dimmer 1          | 0-255              | 0-100%                                    |
| 31           |       |      |      |      |      | Dimmer 1 16bit    | 0-255              | 0-100%                                    |
| 32           | 32    | 25   |      |      |      | R(C)1             | 0-255              | 0-100%                                    |
| 33           | 33    |      |      |      |      | R(C)1 16bit       | 0-255              | 0-100%                                    |
| 34           | 34    | 26   |      |      |      | G(M)1             | 0-255              | 0-100%                                    |
| 35           | 35    |      |      |      |      | G(M)1 16bit       | 0-255              | 0-100%                                    |
| 36           | 36    | 27   |      |      |      | B(Y)1             | 0-255              | 0-100%                                    |
| 37           | 37    |      |      |      |      | B(Y)1 16bit       | 0-255              | 0-100%                                    |
| 38           |       |      |      |      |      | Dimmer 2          | 0-255              | 0-100%                                    |
| 39           |       |      |      |      |      | Dimmer 2 16bit    | 0-255              | 0-100%                                    |
| 40           | 38    | 28   |      |      |      | R(C)2             | 0-255              | 0-100%                                    |
| 41           | 39    |      |      |      |      | R(C)2 16bit       | 0-255              | 0-100%                                    |
| 42           | 40    | 29   |      |      |      | G(M)2             | 0-255              | 0-100%                                    |
| 43           | 41    |      |      |      |      | G(M)2 16bit       | 0-255              | 0-100%                                    |
| 44           | 42    | 30   |      |      |      | B(Y)2             | 0-255              | 0-100%                                    |
| 45           | 43    |      |      |      |      | B(Y)2 16bit       | 0-255              | 0-100%                                    |



| Mode/Channel |       |      |      |      |      | Channel Name        | DMX   | Function |
|--------------|-------|------|------|------|------|---------------------|-------|----------|
| 135CH        | 111CH | 64CH | 30CH | 24CH | 15CH |                     |       |          |
| .            | .     | .    |      |      |      | .                   | .     | #N/A     |
| .            | .     | .    |      |      |      | .                   | .     | #N/A     |
| .            | .     | .    |      |      |      | .                   | .     | #N/A     |
| .            | .     | .    |      |      |      | .                   | .     | #N/A     |
| 118          |       |      |      |      |      | dimmer 12           | 0-255 | 0-100%   |
| 119          |       |      |      |      |      | dimmer 12 16bit     | 0-255 | 0-100%   |
| 120          | 98    | 58   |      |      |      | R(C)12              | 0-255 | 0-100%   |
| 121          | 99    |      |      |      |      | R(C)12 16bit        | 0-255 | 0-100%   |
| 122          | 100   | 59   |      |      |      | G(M)12              | 0-255 | 0-100%   |
| 123          | 101   |      |      |      |      | G(M)12 16bit        | 0-255 | 0-100%   |
| 124          | 102   | 60   |      |      |      | B(Y)12              | 0-255 | 0-100%   |
| 125          | 103   |      |      |      |      | B(Y)12 16bit        | 0-255 | 0-100%   |
| 126          |       |      |      |      |      | dimmer 13 (center)  | 0-255 | 0-100%   |
| 127          |       |      |      |      |      | dimmer 13 (center)  | 0-255 | 0-100%   |
| 128          | 104   | 61   |      |      |      | R(C)13(center)      | 0-255 | 0-100%   |
| 129          | 105   |      |      |      |      | R(C)13(center)16bit | 0-255 | 0-100%   |
| 130          | 106   | 62   |      |      |      | G(M)13(center)      | 0-255 | 0-100%   |
| 131          | 107   |      |      |      |      | G(M)13(center) 16b  | 0-255 | 0-100%   |
| 132          | 108   | 63   |      |      |      | B(Y)13(center)      | 0-255 | 0-100%   |
| 133          | 109   |      |      |      |      | B(Y)13(center)16bit | 0-255 | 0-100%   |
| 134          | 110   | 64   |      |      |      | W13(center)         | 0-255 | 0-100%   |
| 135          | 111   |      |      |      |      | W13(center)16bit    | 0-255 | 0-100%   |